



Acer AL1916 Stand Replacement

This guide will show the user how to remove the stand.

Written By: Keith



INTRODUCTION

The stand supports the monitor from falling over.



TOOLS:

- [Phillips #2 Screwdriver](#) (1)



PARTS:

- [Stand](#) (1)

Step 1 — Stand



- ① Lay the monitor on a flat surface so that the back is facing up.

Step 2



- Grab the hinge cover with both hands on either side of the stand.
- Squeeze inwards with your thumbs and fingers and lift up to remove the hinge cover.

Step 3



- Remove the four 12.1 mm Phillips #2 screws that hold the stand to the monitor.
- ⚠ Support the monitor while removing the screws to prevent the monitor from falling.
- Lift up to detach the stand.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-18 07:30:25 AM.